

[*SGML Version See Change Record*]
TECHNICAL MANUAL

INSTALLATION OPERATION AND
MAINTENANCE INSTRUCTIONS

STEAM JACKETED KETTLES

LT - TYPE 1, STYLE 1, CLASS B
LTWT - TYPE 1, STYLE 2, CLASS B
LP - TYPE 1, STYLE 3, CLASS B

DISTRIBUTION STATEMENT E: DISTRIBUTION AUTHORIZED TO DOD COMPONENTS ONLY; CRITICAL TECHNOLOGY; DATE OF PUBLICATION. OTHER REQUESTS SHALL BE REFERRED TO THE NAVAL SEA SYSTEMS COMMAND (SEA-09B2).

WARNING: THIS DOCUMENT CONTAINS TECHNICAL DATA WHOSE EXPORT IS RESTRICTED BY THE ARMS EXPORT CONTROL ACT (TITLE 22, U.S.C. SEC. 2751 ET. SEQ.) OR EXECUTIVE ORDER 12470. VIOLATIONS OF THESE EXPORT LAWS ARE SUBJECT TO SEVERE CRIMINAL PENALTIES.

DESTRUCTION NOTICE: DESTROY BY ANY METHOD THAT WILL PREVENT DISCLOSURE OF CONTENTS OR RECONSTRUCTION OF THE DOCUMENT.

RECORD OF CHANGES

CHANGE NO.	DATE	TITLE OR BRIEF DESCRIPTION	ENTERED BY

NOTE

THIS TECHNICAL MANUAL (TM) HAS BEEN DEVELOPED FROM AN INTELLIGENT ELECTRONIC SOURCE KNOWN AS STANDARD GENERALIZED MARKUP LANGUAGE (SGML). THERE IS NO LOEP. ALL CHANGES, IF APPLICABLE, ARE INCLUDED. THE PAGINATION IN THIS TM WILL NOT MATCH THE PAGINATION OF THE ORIGINAL PAPER TM; HOWEVER, THE CONTENT IS EXACTLY THE SAME. ANY CHANGES RECEIVED AFTER RECEIPT OF THIS TM WILL ONLY FIT IN THIS PAGINATED VERSION.

FOREWORD

Ships, training activities, supply points, depots, Naval Shipyards and Supervisors of Shipbuilding are requested to arrange for the maximum practical use and evaluation of NAVSEA technical manuals. All errors, omissions, discrepancies, and suggestions for improvement to NAVSEA technical manuals shall be reported to the Commander, NAVSURFWARCENDIV, 4363 Missile Way, Port Hueneme, CA 93043-4307 on NAVSEA/ SPAWAR Technical Manual Deficiency/Evaluation report (TMDER), NAVSEA Form 4160/1. To facilitate such reporting, one copy of NAVSEA Form 4160/1 is included at the end of each bound part of each technical manual. All feedback comments shall be thoroughly investigated and originators will be advised of action resulting therefrom. Extra copies of NAVSEA Form 4160/1 may be requisitioned from DDSP Susquehanna Pennsylvania, 05 E Street, Mechanicsburg, PA 17055-5003. (S/N 0116-LP-019-5300).

TABLE OF CONTENTS

Chapter/Paragraph	Page
SECTION GENERAL INFORMATION	1-1
SECTION INSTALLATION INSTRUCTIONS	1-1
2.1 KETTLE MOUNTING- LP SERIES	1-1
2.2 KETTLE MOUNTING- LT SERIES	1-2
2.3 KETTLE MOUNTING- LTWT SERIES.	1-2
2.4 PLUMBING	1-2
SECTION OPERATING INSTRUCTIONS	1-2
SECTION REPAIR	1-3
SECTION MAINTENANCE	1-11
SECTION TROUBLE SHOOTING	1-27
SECTION PARTS LISTS	1-27
7.1 ITEM DESCRIPTIONS	1-27
7.2 MANUFACTURERS LIST	1-28

LIST OF TABLES

Table	Title	Page
	TROUBLESHOOTING	1-27
	ITEM DESCRIPTIONS	1-27
	MANUFACTURERS' LIST	1-28

LIST OF ILLUSTRATIONS

Figure	Title	Page
	TS-116A	1-5
	TS-117A (Sheet 1 of 2)	1-7
	TS-114A	1-13
	TS-122A	1-15
	R-328A	1-19
	R-162C-M	1-21
	R-322A	1-23
	A-4	1-25

SAFETY SUMMARY

GENERAL SAFETY NOTICES THE FOLLOWING GENERAL SAFETY NOTICES SUPPLEMENT THE SPECIFIC WARNINGS AND CAUTIONS APPEARING ELSEWHERE IN THIS MANUAL. THEY ARE RECOMMENDED PRECAUTIONS THAT MUST BE UNDERSTOOD AND APPLIED DURING OPERATION AND MAINTENANCE OF THE EQUIPMENT COVERED HEREIN. SHOULD SITUATIONS ARISE THAT ARE NOT COVERED IN THE GENERAL OR SPECIFIC SAFETY PRECAUTIONS, THE COMMANDING OFFICER OR OTHER AUTHORITY WILL ISSUE ORDERS AS DEEMED NECESSARY TO COVER THE SITUATION.

DO NOT REPAIR OR ADJUST ALONE UNDER NO CIRCUMSTANCES SHOULD REPAIR OR ADJUSTMENT OF ENERGIZED EQUIPMENT BE ATTEMPTED ALONE. THE IMMEDIATE PRESENCE OF SOMEONE CAPABLE OF RENDERING AID IS REQUIRED. BEFORE MAKING ADJUSTMENTS, BE SURE TO PROTECT AGAINST GROUNDING. IF POSSIBLE, ADJUSTMENTS SHOULD BE MADE WITH ONE HAND, WITH THE OTHER HAND FREE AND CLEAR OF EQUIPMENT. EVEN WHEN POWER HAS BEEN REMOVED FROM EQUIPMENT CIRCUITS, DANGEROUS POTENTIALS MAY STILL EXIST DUE TO RETENTION OF CHARGES BY CAPACITORS. CIRCUITS MUST BE GROUNDED AND ALL CAPACITORS DISCHARGED PRIOR TO ATTEMPTING REPAIRS.

TEST EQUIPMENT MAKE CERTAIN TEST EQUIPMENT IS IN GOOD CONDITION. IF A TEST METER MUST BE HELD, GROUND THE CASE OF THE METER BEFORE STARTING MEASUREMENT; DO NOT TOUCH LIVE EQUIPMENT OR PERSONNEL WORKING ON LIVE EQUIPMENT WHILE HOLDING A TEST METER. SOME TYPES OF MEASURING DEVICES SHOULD NOT BE GROUNDED; THESE DEVICES SHOULD NOT BE HELD WHEN TAKING MEASUREMENTS.

INTERLOCKS INTERLOCKS ARE PROVIDED FOR SAFETY OF PERSONNEL AND EQUIPMENT AND SHOULD BE USED FOR THE PURPOSE INTENDED. THEY SHOULD NOT BE BATTLE SHORTED OR OTHERWISE MODIFIED EXCEPT BY AUTHORIZED MAINTENANCE PERSONNEL. DO NOT DEPEND SOLELY UPON INTERLOCKS FOR PROTECTION. WHENEVER POSSIBLE, DISCONNECT POWER AT POWER DISTRIBUTION SOURCE.

CAUTIONS TO USER

STEAM SUPPLY SHOULD NOT EXCEED 55 PSIG.

DO NOT TURN ON STEAM UNLESS FOOD OR WATER IS IN KETTLE.

DO NOT TAMPER WITH OR OBSTRUCT SAFETY VALVE.

DO NOT PUT WATER IN A HOT, DRY KETTLE.

DO NOT CLEAN WITH ABRASIVE MATERIALS.

WARNING

- BEFORE REPAIRING, CLEANING, OR REPLACING PARTS, CLOSE ALL STEAM, WATER, AND CONDENSATE VALVES (INCLUDING APPLICABLE VALVES ON CUSTOMER SUPPLY PIPING). (Page 1-3)

CHAPTER 1

SECTION

GENERAL INFORMATION

1.1

LEGION STEAM KETTLES ARE MANUFACTURED FROM SEAMLESS DRAWN, ONE PIECE STAINLESS STEEL BLANKS IN GAUGES REQUIRED TO QUALIFY FOR ASME INSPECTION, AND STAMPING. THERE ARE NO JOINTS, WELDS OR GRIND MARKS IN LEGION SHELLS. THIS OUTSTANDING DESIGN FEATURE SETS LEGION KETTLES APART FROM COMPETITIVE DESIGNS USING SHELLS MADE OF WELDED SECTIONS. A SEAMLESS DRAWN SHELL IS THE SUPERIOR DESIGN FOR SANITARY AND STRUCTURAL REQUIREMENTS AND ELIMINATES COMPLETELY THE POSSIBILITY OF WEAKENED JOINTS DUE TO EXCESSIVE GRINDING OR CORROSIVE ATTACK DUE TO IMPERFECTIONS IN THE WELD. ALL LEGION KETTLES ARE MANUFACTURED OF 18-8 STAINLESS STEEL TYPE 304, FINISHED IN A #4 COMMERCIAL GRIT AND COMPOUNDED TO A SANITARY CUSTOM LUSTRE.

1.2

ALL STEAM JACKETED KETTLES FEATURE LEGION'S DIE FORMED ONE PIECE INTEGRAL OPEN SANITARY BEAD DESIGN PREFERRED BY ALL HEALTH AUTHORITIES AND RESULTING IN A TRULY SANITARY, EASY TO CLEAN, YET STRUCTURALLY RIGID KETTLE RIM. THE OPEN RIM DESIGN, RETURNED 180 DEGREES, IS A SIGNIFICANT IMPROVEMENT OVER THE HARD TO CLEAN EARLIER, WIRE REINFORCED RIM, THAT MUST BE CONTINUOUSLY WELDED AND GROUND IN ORDER TO ELIMINATE CREVICES AND JOINTS IN INACCESSIBLE PLACES.

1.3

ALL LEGION PRESSURE KETTLES, STEAM, GAS OR ELECTRIC ARE DESIGNED AND BUILT IN COMPLIANCE WITH THE REQUIREMENTS OF THE LATEST ASME CODE, SECTION VIII FOR UNFIRED PRESSURE VESSELS AND ARE SO STAMPED AND/OR SHOP INSPECTED, IF SO SPECIFIED.

1.4

STEAM JACKETED KETTLES FOR SHIPBOARD USE ARE FOR USE WITH 55 PSI (MAX) STEAM.

SECTION

INSTALLATION INSTRUCTIONS

2.1 KETTLE MOUNTING- LP SERIES

2.1.1 LEVEL DESIGNATED AREA FOR KETTLES MOUNTING ON PEDESTAL BASE.

2.1.2 TRANSFER DRILL HOLES LOCATED ON PEDESTAL BASE TO MOUNTING SURFACE FOR 3/8" BOLTS, FOR SCREWS 4 REQUIRED (SCREWS OR BOLTS SUPPLIED BY OTHERS).

2.1.3 APPLY STYLASTIC (DOW CORNING #RTU-73200 OR EQUIVALENT) AROUND PERIMETER OF PEDESTAL BASE AND MOUNTING SURFACE TO CLOSE EXISTING CREVICES.

2.2 KETTLE MOUNTING- LT SERIES

2.2.1 TRANSFER HOLES FOR 3/8" BOLTS FROM FLANGED FEET TO THE MOUNTING SURFACE. INSTALL KETTLE ON BOLTS (SUPPLIED BY OTHERS).

2.3 KETTLE MOUNTING- LTWT SERIES.

2.3.1 INSTALL WALL BRACKETS ON BOLTS. SEE DRAWING R-325, P. 13 FOR LOCATION OF BOLTS.

2.4 PLUMBING

2.4.1 ASSEMBLE PLUMBING PARTS PER DRAWING A-4, P.15, CONNECT PLUMBING ASSEMBLIES TO KETTLE.

2.4.2 CONNECT STEAM INLET PLUMBING TO STEAM SUPPLY LINE. CONNECT CONDENSATE PLUMBING TO WASTE LINE OR DRAIN.

SECTION OPERATING INSTRUCTIONS

3.1

WASH KETTLE BEFORE AND AFTER EACH USE WITH HOT SOAPY WATER AND RINSE THOROUGHLY WITH CLEAN HOT WATER.

3.2

WHEN HEATING A COLD KETTLE, TURN THE STEAM ON GRADUALLY, THUS ALLOWING THE KETTLE TO BECOME WARM BEFORE FULL PRESSURE IS APPLIED. AFTER KETTLE BECOMES WARM, AND BEFORE APPLYING FULL PRESSURE, OPEN SAFETY VALVE MOMENTARILY TO RELEASE ANY AIR TRAPPED WITHIN THE JACKET.

3.3

CLEAN STRAINER, DRAWOFF VALVE, AND DRAWOFF TUBE THOROUGHLY AFTER EACH USE. TO CLEAN DRAWOFF VALVE AND TUBE REMOVE THE FRONT END OF THE VALVE AND BRUSH-SCRUB WITH HOT WATER.

3.4

LEAVE COVER AND DRAIN OPEN WHEN NOT IN USE.

SECTION REPAIR

WARNING

- BEFORE REPAIRING, CLEANING, OR REPLACING PARTS, CLOSE ALL STEAM, WATER, AND CONDENSATE VALVES (INCLUDING APPLICABLE VALVES ON CUSTOMER SUPPLY PIPING).

4.1

THE STRAINER MAY BE CLEANED OR THE BASKET REPLACED, WITHOUT REMOVING IT FROM THE PIPING SYSTEM. SEE P.5.

4.2


ALL LEGION SUPPLIED VALVES, TRAPS AND FITTINGS HAVE SCREWED CONNECTIONS. IF A LEAK OCCURS AT A CONNECTION, REMOVE APPROPRIATE COMPONENTS AND INSPECT THEIR THREADS. IF THREADS ARE DAMAGED, REPLACE COMPONENTS; IF NOT, REINSTALL PIPING. TEFLON TAPE SHOULD BE USED ON ALL THREADED CONNECTIONS.

4.3

IF THE FILL FAUCET LEAKS, REPLACE WASHER(S) IN FAUCET.

4.4

IF THE DRAWOFF FAUCET LEAKS, REMOVE NUT AND REPLACE STEM, SEE P.6. IF THE FAUCET BECOMES DAMAGED, REPLACE THE FAUCET. SEE P. 7.



SIZE NPT	A	B	C	CAT. NO. (B.I.)	CAT. NO. (I.C.P.)
1/2	3 3/4	1 1/2	1 7/8	450023	440360
3/4	4 1/2	1 7/8	2 1/16	450000	440361
1	5 3/8	2 3/8	2 3/8	450193	450493

STRAINERS

Line strainers are used on steam operated equipment to protect a trap, a steam valve or a solenoid valve from becoming clogged due to impurities floating in the steam.

When steam lines are very dirty, sludge and other material may clog a strainer completely. To clean out a strainer, the hexagon cap must be removed and the brass screen thoroughly cleaned.


When replacing the inner strainer basket care must be taken to bottom the tapered end of the screen firmly into the cast body and screw the hexagon cap sufficiently deep into the body to arrest the internal strainer in a locked position. If the screen is allowed to float freely within the strainer, the entire purpose of the strainer is defeated.

The strainers are rated for 250 lbs and made in cast iron. They can be had in chromeplated or gray paint finish. We employ a special brass screen on the inside with .018 perforations. Strainers have an arrow cast on the outside of the body to indicate direction of flow.

NOTE: When ordering parts, always refer to complete catalog number, serial number and capacity of the kettle involved.

Cast Iron strainers gray paint finish or chromeplated as used on LEGION steam jacketed kettles.

LEGION EQUIPMENT CO INC			
DWN: L.A.	DATE: 1-1-67	TS 116A	
APP'D	SCALE: 2		
REV: A	ECL 72B		
REV:	REV:		



SIZE	CAT. NO.	A	B	C	D	E	F	G
1½"	440057	1 1/8"	2"	2 1/2"	1 1/2"	7 1/2"	6 1/2"	1 3/4"
2"	440019	1 3/8"	2 1/4"	3 1/8"	2"	10 1/4"	8 1/4"	2 1/2"
3"	440235	2 1/8"	3 1/4"	4"	3"	13 1/2"	10 1/2"	3 1/8"

WHEN ORDERING PARTS, SPECIFY WHETHER THEY ARE WANTED FOR 1½" (440057) OR 2" (440019) SIZE.
FOR INSTALLING FAUCET REFER TO SHEET 2.

FAUCET, STANDARD 1½", 2" AND 3" DAIRY METAL COMPRESSION TYPE TANGENT STEAM KETTLE DRAW-OFF

LEGION EQUIPMENT COMPANY			
DATE ORDERED	DATE	5/29/75	
BY 6453	DATE	6/2/75	TS-117
REVISED	DATE		SHEET 1 OF 2

TS-117A (Sheet 1 of 2)

In order to install a new faucet of the plug or compression type, remove all parts from the faucet leaving only the faucet body on the draw-off tube.

1. Heat up solder joints in rear of the faucet with a blow torch (Benz O Matic) until the solder starts dripping. Tap faucet body gently from the rear while welding; use a rubber mallet or a piece of wood and make sure the faucet is not allowed to drop.
2. After the faucet body has been removed, add acid (All State Duzall) to the draw-off tube. Heat it slightly and add solder for retinning. Wipe off excess solder so that the draw-off tube is completely tinned and smooth.
3. To install new faucet, likewise remove all inner parts and handles and brush some acid on the recessed seating opening in the back of the faucet and add solder. Wipe inside clean so that the entire recessed bore is tinned. This coat of tin must be very thin and care must be taken that neither acid nor tin find their way into the valve body.
4. Now, brush acid on the faucet and draw-off tube and slip faucet body gently onto draw-off tube making sure that the body bottoms on the draw-off tube.
5. Apply the blow torch and heat slightly all around. Add solder while heating. Very little solder is needed. If too much solder is applied, it will enter into the valve seat region and this must be avoided. When finished, cool water and wash clean. Use 50 - 50 solder.
6. It is helpful to tilt the kettle forward so that the draw-off tube is close to a vertical position. However, this is not absolutely necessary if the mechanic is skilled in soldering procedures.

For detailed dimensions of draw-off faucets, refer to:

Drawing TS-117A Dairy metal 1½" (#440057) and 2" (#440019)
compression faucets (standard)

**Drawing TS-119A Dairy metal 1½" (#440017) plug type draw-off faucet (standard) - Obsolete as of 1/1971

Drawing TS-118A Dairy metal 1½" (#440017) and 2" (#440073)
plug type draw-off faucets with bayonet lock

INSTRUCTIONS FOR INSTALLING NEW
TANGENT DRAW-OFF COMPRESSION TYPE
FAUCET OR PLUG TYPE FAUCET ON LEGION
KETTLES

LEGION EQUIPMENT CO., INC.			
DWN ALO	DATE 6/2/75	TS-117	
APP CBR	DATE 6/2/75		
ECN T15	REV. B		

SECTION MAINTENANCE

5.1

CHECK SAFETY VALVE PERIODICALLY TO INSURE THAT IT IS FUNCTIONING PROPERLY.

5.2

CHECK ALL GLOBE AND/OR GATE VALVES TO INSURE THAT THEY ARE OPENING AND CLOSING PROPERLY.

5.3

CHECK STRAINERS, CHECK VALVE AND BUCKET TRAP TO ENSURE THAT THE STEAM LINES ARE NOT CLOGGED.

5.4

KETTLE SHOULD BE WASHED BEFORE AND AFTER EACH USE WITH HOT SOAPY WATER AND RINSED THOROUGHLY WITH CLEAN WATER. DRY THOROUGHLY.

5.5

CLEAN STRAINER (KETTLE) BEFORE AND AFTER EACH USE WITH HOT SOAPY WATER AND RINSE THOROUGHLY.

5.6


THE STAINLESS STEEL SURFACE OF THE UNIT MAY BE POLISHED WITH ANY REPUTABLE COMMERCIAL STAINLESS STEEL CLEANER.

5.7

NEVER USE STEEL WOOL OR ANY ABRASIVE FOR CLEANING.

5.8

THE KETTLE MAY BE HYDROSTATICALLY PRESSURE TESTED WHILE IN LINE. UNDER NO CIRCUMSTANCES SHOULD THE KETTLE BE EXPOSED TO A TEST PRESSURE EXCEEDING 95 PSIG. BEFORE PRESSURE TESTING, THE RELIEF VALVE, ELBOWS, AND NIPPLE (ITEMS 1, 2, AND 3; P.15) MUST BE REMOVED FROM THE RELIEF VALVE COUPLING AND A 3/4", 150 LB PIPE PLUG INSTALLED.



The #60 trap has the purpose to discharge condensate on the discharge side of all steam jacketed kettles. The traps are rated for operating pressures up to 250 lbs. and are furnished with a seat for intermittent pressure from 75 to 125 P.S.I.

FUNCTION OF INVERTED BUCKET TRAPS:

As the steam condensate enters into the trap body, rising in the main chamber and bucket which is open at the bottom, the air in the bucket is pushed out through the air vent. This makes the bucket lose its boyancy. Eventually the bucket drops and opens the discharge port by means of a linkage system. The water is now pushed out by the steam pressure and when it is completely discharged, the bucket, regaining its original boyancy, is rising again closing the discharge orifices. In similar manner as before, water is now again accumulating in the trap chamber, repeating the process.

The material of the trap is high grade cast iron with the seating material in stainless steel. All internal parts are brass and copper. The finish is either chromeplated or painted.


In order to protect the smooth operation of the trap, a strainer should be installed ahead of the trap.

Steam traps must be periodically cleaned of sludge and this is done by removing drain plug #14.

The discharge capacity of the #60 trap with a steam pressure range from 20 to 50 lbs. is approximately 1000 lbs. of water per hour.

440205 1/2 NPT } chromeplated
440206 3/4 NPT }
LEGION #60 intermittent inverted
bucket trap, steam 1/2 & 3/4 NPT

LEGION EQUIPMENT CO INC			
DWN L.A.	DATE	J-1-67	TS114A
APP'D	SCALE		
REV:	REV:		
REV:	REV:		



These strainers are of the self-locking type and are inserted into the tangent draw-off tube. In order to lock them securely into place, the strainer must be pulled forward in the direction of the draw-off tube.

When the strainer is properly inserted the peripheral edge of the 9" strainer plate must contact the inner kettle shell.


If the prongs fit too tightly or too loosely, the spring action of the prong can be corrected by spreading or closing the prong.

NOTE: When ordering parts, always refer to complete catalog number, serial number and capacity of the kettle involved.

Legion standard tangent strainer to fit all
steam jacketed kettles with tangent
draw-off faucets.

LEGION EQUIPMENT CO., INC.
OWN: L.A. DATE: 1-1-67
APP'D: SCALE: TS

TS-122A



These strainers are of the self-locking type and are inserted into the tangent draw-off tube. In order to lock them securely into place, the strainer must be pulled forward in the direction of the draw-off tube.

When the strainer is properly inserted the peripheral edge of the 9" strainer plate must contact the inner kettle shell.

If the prongs fit too tightly or too loosely, the spring action of the prong can be corrected by spreading or closing the prong.


NOTE: When ordering parts, always refer to complete catalog number, serial number and capacity of the kettle involved.


P/N 404939-001


Legion standard tangent strainer to fit all steam jacketed kettles with 3" tangent draw-off faucets.

LEGION EQUIPMENT CO. INC.	
DWN: L.A.	DATE: 1-1-67
APP'D	SCALE: 1/2" = 1"
REV:	REV:
REV:	REV:

TS
122A
SHEET 1A







SECTION TROUBLE SHOOTING

6.1

OPEN STEAM SUPPLY VALVE TO KETTLE (ITEM 4, P.20), OPERATE SAFETY VALVE LEVER.

TROUBLESHOOTING

<u>SYMPTOM</u>	<u>POSSIBLE CAUSE</u>	<u>REMEDY</u>
STEAM DISCHARGED FROM SAFETY VALVE	CLOGGED STRAINER	CLEAN STRAINER BASKET
	STEAM TRAP FAILURE	REPLACE STEAM TRAP
	CLOGGED CONDENSATE PIPING	CLEAN CLOGGED COMPONENT
STEAM NOT DISCHARGED FROM SAFETY VALVE	GLOBE VALVE FAILURE	REPLACE GLOBE VALVE
	CLOGGED STEAM SUPPLY PIPING	CLEAN CLOGGED COMPONENT

SECTION PARTS LISTS

7.1 ITEM DESCRIPTIONS

ITEM DESCRIPTIONS

REG'D	DESCRIPTION	VENDOR CODE INDENT.	MFG'S MOD. NO.	INV. CON- TROL NUM- BER	DWG. NO.
1	DRAWOFF FAUCET 1-1/2"	35550	PROPRIETARY	440057	TS-117A
1	DRAWOFF FAUCET 2"	35550	PROPRIETARY	440019	TS-117A
1	DRAWOFF FAUCET 3"	35550	PROPRIETARY	440235	TS-117A
1	STRAINER 1-1/2" & 2"	35550	PROPRIETARY	400270	TS-122A
1	STRAINER 3"	35550	PROPRIETARY	404939-001	TS-122A
1	SAFETY VALVE SS#	72219	10-301-50	440173	
1	FAUCET B-206	06212	B-206	440027	
1	CHAIN ASSY, SAFETY VALVE	35550	PROPRIETARY	405199	

7.2 MANUFACTURERS LIST

MANUFACTURERS' LIST

FED. MFR. CODE	MFR. & LOCATION
35550	LEGION UTENSILS CO., INC. P.O. BOX 296 AUGUSTA, GA 30901-0296
06212	T & S BRASS BRONZE CO. RT.4 OLD BUNCOMBE RD. TRAVLERS REST, SC 29690
72219	CONSOLIDATED BRASS CO. P.O. BOX 247 MATTHEWS, NC 28105

REAR SECTION**TECHNICAL MANUAL DEFICIENCY/EVALUATION REPORT(TMDER)****NOTE**

Ships, training activities, supply points, depots, Naval Shipyards, and Supervisors of Shipbuilding are requested to arrange for the maximum practical use and evaluation of NAVSEA technical manuals. All errors, omissions, discrepancies, and suggestions for improvement to NAVSEA technical manuals shall be reported to the Commander, NAVSURFWARCENDIV, 4363 Missile Way, Port Hueneme, CA 93043-4307 in NAVSEA/SPAWAR Technical Manual Deficiency/Evaluation Report (TMDER), NAVSEA Form 4160/1. To facilitate such reporting, print, complete, and mail NAVSEA Form 4160/1 below or submit TMDERS at web site <http://nsdsa.phdnswc.navy.mil/tmder/tmder.htm>. All feedback comments shall be thoroughly investigated and originators will be advised of action resulting therefrom. Extra copies of NAVSEA Form 4160/1 may be requisitioned from DDSP Susquehanna Pennsylvania, 05 E Street, Mechanicsburg, PA 17055-5003. (S/N 0116-LP-019-5300)

TMDER / MAILER

